

Instruction Manual



16 Angle Softbox

WALSER GmbH & Co. KG Senefelderstrasse 23 86368 Gersthofen Germany info@walser.de www.walser.de Congratulation to your new walimex pro 16 Angle Softbox. It consists of first-class materials and is featured through characteristics such as low light loss, extensive light output and high colour saturation for taking photos of medium sized products.

A

- Please read these instructions carefully before using your device for the first time. It
 includes everything you need to know to avoid physical injuries and damages.
- Please note all safety notes in this instruction manual.
- Please keep this manual safe. In case of selling or leaving the device to other persons, please don't forget to hand this manual over as well.

1. How to understand this instruction manual

Markings in this manual

Marking	Meaning
A	Indicates the handling and consequences of safety notes.
	Indicates a hazardous situation, which, if not avoided, could result in a serious injury.
A CAUTION	Indicates a hazardous situation, which, if not avoided, may result in minor or moderate injury.
ADVICE:	Indicates potentially physical damages and other important information in connection with your product.

2. Important safety notes

Danger for the eyes The tension of the rods could be a danger for your eyes

- When stretching the rods, please pay attention, that they don't shoot in your eyes.
 Danger of severe eye injury
- Make sure, that all persons, who are not involved in mounting and demounting arrangements, should keep a distance of at least 3m

A Caution

Danger of injury through the tension of the rods

- Make sure, that your fingers will not be squeezed when fixing the rods to the speedring
- Make sure, that all persons, who are not involved in mounting and demounting arrangements, should keep a distance of at least 3m

WARNING

Danger of burning through hot parts

The speedring and the softbox adapter could heat up depending on your studio flash device. Easy inflammable materials could keep fire, if they are too near or if they are not mounted correctly.

A Make sure, that easily inflammable materials don't get in contact with the studio flash device

A Warning

Danger of burning on hot parts

The modeling lamp and the flash tube as well as the speedring and softbox adapter could heat up depending on your studio flash device

- Don't touch these parts during operation and cooling down
- Let the studio device cool down according to the specifications in the instruction manual before starting any mounting or maintenance arrangements
- Don't touch in the softbox or change the inner diffusor during operation and cooling down

ADVICE: Please mount and demount this item with two persons.

We recommend to use this item with flash devices from at least 400Ws

We reserve the right to make technical and optical modifications in the course of product improvement.

3. Unpack and check the product

- Please unpack the product carefully. ADVICE: Keep the original box and the bag for future storage and transportation.
- 2. Please check, if the delivery is complete:
 - 1 x Softbox Cover
 - 1 x Inner Softbox Cover
 - 1 x Speedring with Tripod Mounting
 - 16 x Rods
 - 1 x Inner Diffusor
 - 1 x Front Diffusor
 - 1 x Instruction Manual in German and English

3. Please check, if the delivery is undamaged.

ADVICE: If the delivery should be uncomplete or damaged, please contact info@walser.de.


4. Assembly instruction

Step I

Lay the softbox cover on the ground and open all Velcro fasteners. Put the speedring with the tripod mount in the center. The tripod mount must show backwards to the ground. Insert <u>4</u> rods with the big socket into the lugs of the softbox


Step II

Slide the end piece of the rods with the slim socket into the speedring



Step III

For the further simple assembly, mount the Softbox with the tripod mount on a stable tripod (e.g. item 16564 walimex pro Lamp Tripod AIR Deluxe, max. load capacity from approx. 20kg). Put the other rods successively into the speedring. For getting the right tension, slide the softbox cover forward and insert the rods into the lugs of the softbox.



WARNING


When stretching the rods, please pay attention, that they don't shoot in your eyes. Danger of severe eye injury

A Caution

Danger of injuries and physical injuries through the tension of the rods during mounting and demounting. Keep a distance from at least 3m to the product.

Step IV

Close the back side of the softbox cover with the Velcro fastener.



Step V

Fix the softbox adapter on the universal connection of the softbox with the screws on the speedring.

Put the inner softbox cover around the speedring and fix it with the Velcro fastener.



Step VI

You can mount your studio flash device on the softbox adapter. Make sure, that it is locked securely in the softbox adapter. The studio flash device is levitating and cannot be mounted on a tripod. The studio flash can be mounted diagonal and serves as counterweight for the softbox.





Step VII

Attach the inner diffusor on the inner Velcro fastener. Afterwards you can put the front diffusor over the edges of the softbox.





5. Maintenance

Let the softbox cool down completely before cleaning. Clean the softbox and diffusor only with a wet cloth. Please use the original box or carrying bag for transportation or storage.