

Lichtwürfel 230 x 160 x 160 cm

Shooting Tent 230 x 160 x 160 cm



D


Wir freuen uns, dass Sie sich für ein Walimex pro Produkt aus dem Hause WALSER entschieden haben und wünschen Ihnen viel Freude mit unserem Produkt.

WALSER bietet seinen Kunden mit den Marken Walimex pro und Mantona preiswerte, ausgewählte und exklusive Produkte für kreative Foto- und Videografie direkt vom Hersteller.

Dabei profitieren sowohl ambitionierte Anfänger wie auch Profis von unserem Produkt-Know-how und einem ausgezeichneten Service. Ob Fragen zu technischen Details oder zu Einsatzgebieten unserer Produkte – mit einer individuellen Fachberatung durch ausgebildete Fotografen unterstützen wir unsere Kunden auch nach dem Kauf in allen Aspekten rund um unser Portfolio.


Teilen Sie unsere Begeisterung für professionelle Foto- und Videografie und lassen auch Sie sich von unseren Produkten inspirieren!

Ihr Team von WALSER


**Zeltstangen**

- A 8x
- B 8x
- C 8x
- D 4x
- E 1x
- F 1x

Setzen Sie 8 identische Ecken zusammen aus jeweils 1x A, 1x B und 1x C. Lockern Sie hierzu die Innensechskantschrauben der Muffen. Dann verschränken Sie jeweils 1x B und C im rechten Winkel wie im Bild gezeigt und führen 1x A mit der abgeschlossenen Seite in die Muffe ein. Stellen Sie den rechten Winkel zwischen B und C sicher und ziehen Sie die Innensechskantschrauben wieder an.





Stellen Sie sicher, dass alle 8 Ecken identisch sind.




Setzen Sie den Boden des Lichtwürfels aus vier Ecken zusammen, wie im Bild gezeigt. Führen Sie dazu die Steckverbindungen schließend zusammen.

Tipp: Sollten Sie den Lichtwürfel länger als nur für ein Shooting nutzen wollen, können Sie alle Steckverbindungen zusätzlich mit Gewebepband (Gaffer Tape) fixieren.



Setzen Sie nun die Decke ebenfalls aus vier Ecken zusammen. Aus den Bauteilen E und F können Sie optional eine Traverse einbauen, an die Sie bis zu 2 kg schweres Equipment hängen können. Da sich die Muffen mit dem Innensechskantschlüssel öffnen und schließen lassen, können Sie diese auch nachträglich einbauen.



Stecken Sie nun die verbliebenen 4x4 wie gezeigt in die Ecken und setzen Sie dann die Decke darauf. Ziehen Sie hierzu eine zweite Person zu Hilfe.



Anschließend ziehen Sie das Diffusorzelt über und fixieren die Seitenwände mit Hilfe der Klettstreifen um die Stangen, wo vorhanden.

HINWEIS

Ziehen Sie zum Schluss alle Schrauben mit dem Innensechskantschlüssel nochmals nach.

Wir sind für Sie da!

Sollten Sie Hilfe oder eine kostenfreie, individuelle Beratung durch unser geschultes Fachpersonal benötigen, dann freuen wir uns, wenn Sie mit unserem Serviceteam Kontakt aufnehmen.

Wir helfen Ihnen gerne!

Ihr Team von WALSER

E-Mail/Homepage

info@walser.de

www.walser.de

Unsere Postanschrift:

WALSER GmbH & Co. KG

Senefelderstraße 23

86368 Gersthofen

Deutschland



Unser Garantieverprechen

WALSER ist bekannt für seine hochwertige Verarbeitung, beste Funktionalität und einen kundennahen Service. Um unserem außergewöhnlichen Serviceniveau zusätzlichen Ausdruck zu verleihen, geben wir für dieses **Walimex pro** Produkt eine Garantie von 2 Jahren. Diese Garantie ist nur in Verbindung mit Ihrem Kaufbeleg gültig.

Wenn Sie unsere Garantie in Anspruch nehmen wollen, kontaktieren Sie uns bitte per Mail unter info@foto-walser.de.

Unser umfassendes Garantieverprechen und den Garantieumfang finden Sie unter www.foto-walser.de/garantie

Niclas Walser
Inhaber


We are pleased that you have chosen a Walimex pro product from WALSER and wish you lots of pleasure with our product.

With the brands Walimex pro and Mantona, WALSER offers its customers inexpensive, selected and exclusive products for creative photography and videography directly from the manufacturer.

Both ambitious beginners and professionals benefit from our product know-how and excellent service. Whether you have questions about technical details or areas of application for our products - with individual expert advice from trained photographers, we support our customers in all aspects of our portfolio even after the purchase.


Share our enthusiasm for professional photography and videography and let yourself be inspired by our products!

Your team from WALSER




Shooting Tent Poles


- A 8x
- B 8x
- C 8x
- D 4x
- E 1x
- F 1x



Assemble 8 identical corner units from 1 x A, 1 x B and 1 x C. Loosen the hexagon socket screws of the sleeves. Then interlock 1 x B and 1 x C at a right angle as shown in the picture and insert 1 x A with the closed side into the joint. Make sure that the right angle between B and C is maintained and re-tighten the hexagon socket screws.




Make sure that all 8 corner units are identical.




Assemble the base of the light cube from four corner units as shown in the picture. Make sure that the corner connectors are properly connected.

Tip: If you want to use the light cube for longer than just one shooting, you can fix all the plug connections additionally with gaffer tape.



Now assemble the ceiling from four corner units as well. From components E and F, you can optionally install a cross beam on which you can hang equipment weighing up to 2 kg. As the sleeves can be opened and closed with the hexagon socket key, you can also install them subsequently.



Now insert the remaining 4x D into the corners as shown and then place the blanket on top. Bring a second person to help.



Then pull the diffuser tent over and fix the side walls around the poles using the hook-and-loop strips where provided.

NOTE

Please retighten all screws using the socket wrench at the end.

We are here for you!

If you need help or a free, individual consultation from our trained specialist personnel, please contact our service team.

We are happy to help!
Your WALSER Team

Email/homepage

info@walser.de
www.walser.de

Our postal address:

WALSER GmbH & Co. KG
Senefelderstrasse 23
86368 Gersthofen
Germany



Our warranty promise

WALSER is known for its high-quality workmanship, optimal functionality and customer-oriented service. To highlight our exceptional service level, we offer a 2 year warranty for this **Walimex pro** product. This warranty is only valid in combination with your purchase receipt.

If you would like to utilize our warranty, contact us by email at info@foto-walser.de. Our comprehensive guarantee as well as its scope can be found at www.foto-walser.de/en/warranty.

Niclas Walser

Niclas Walser
Founder and Owner

Notizen:

Notizen:

WALSER GmbH & Co. KG
Senefelderstraße 23
86368 Gersthofen
Germany
info@walser.de
www.walser.de
Made in China